


Advanced Incident Management Module

HEMISPHERE® AIM Module for comprehensive registration, localization, logging and documentation of incidents



Function

The HEMISPHERE® Advanced Incident Management Module (AIM) allows the registration, localization and logging of incidents. In addition, all information about an incident can be comprehensively documented with text, images, video and audio.

New Incidents

New incidents can be created automatically by rule-based events or manually by an operator.

Localization

All incidents will be located. Corresponding map data can be transmitted automatically with the event. Manual position marking on the interactive map is also possible at any time.

Information Collection

Operators can quickly enter information about an incident manually in input fields. In addition to standards such as personal data, address data and time, further text fields can be defined according to individual requirements.

Data Archive

Files that contain or log information about an incident can be attached to an incident and stored in an evidence archive. This includes audio and video files, image files, PDF or Word forms.

Search and Filter Functions

The Incidents overview can be evaluated with different filters (time, status, type) and a full text search. The options can be combined with each other.

File Export

Files associated with an incident can be exported to external media or burned directly to CD / DVD.

Backup Link

Backups created with the corresponding application in the SeMSy® Video Management System can be linked to an incident via its identification number.

Configuration

The HEMISPHERE® Advanced Incident Management Module provides a graphical user interface for configuration and operation, which can be accessed platform independently with a web browser.

Hardware

The HEMISPHERE® Advanced Incident Management Module is installed and operated on a dedicated server. The optional Server Rack-Mount 2 RU III is recommended as hardware platform.

Licensing

The license for the HEMISPHERE® Advanced Incident Management Module is managed on the HEMISPHERE® Site Dongle. For the access of the operators to configuration and operation a separate web client license is required for each operator (floating license).

Advanced Incident Management Module

HEMISPHERE® AIM Module for comprehensive registration, localization, logging and documentation of incidents



Module License

006161 **DLD - HEMISPHERE® Advanced Incident Management Module**
License for the use of the AIM module for event and message management, for one instance of the HEMISPHERE® Backbone Server

Client License

006166 **DLD - HEMISPHERE® Web Client Access AIM**
License for the access of one web client to a HEMISPHERE® Advanced Incident Management Module (floating license)

Server

006007.415 **Server Rack-Mount 2 RU III**
Server hardware, 2RU rack-mount, 2x 12-core 2.2GHz CPU, 128 GB DDR4-2400 RAM, 2x redundant power supplies, 1x SATA DOM 64 GB, 2x SSD 1000 GB with RAID 1 (in tray), 6x 3,5" HDDs optional, RAID 6, License for VMware ESXi 6.5 included

