


Evidence Presenter Module

HEMISPHERE® EPM Module for structured documentation and presentation of all stored evidence (text, image, video, audio) of an Incident



Function

The HEMISPHERE® Evidence Presenter Module (EPM) enables the structured creation of presentations based on the files stored in the Advanced Incident Management (AIM) Module for an incident. The result can be exported as a presentation in the form of a movie file.

File Overview

When selecting the number of an incident, the associated files (text, image, video, audio) are clearly displayed in a list view.

Timeline

The different files can be intuitively positioned on a timeline in the desired order for the presentation using drag & drop. The files can be moved in position and resized at any time.

Tracks

A timeline can be structured by different tracks on which the individual files are then placed. Tracks can also be hidden again.

Tools

In addition, it is possible to equip a presentation with text comments and drawing marks. Extensive tools for text fields and paint brushes are available for this purpose.

Positioning

Files can be precisely positioned and arranged by entering coordinates.

Review

Presentations can be displayed for review in any processing status.

Movie Export

The HEMISPHERE® Evidence Presenter Module (EPM) allows to export the created presentation as a movie in MP4 format.

Configuration

The HEMISPHERE® Evidence Presenter Module provides a graphical user interface for configuration and operation, which can be accessed platform independently with a web browser.

Hardware

The HEMISPHERE® Evidence Presenter Module is installed and operated on a dedicated server. The optional Server Rack-Mount 2 RU III is recommended as hardware platform.


Licensing

The license for the HEMISPHERE® Evidence Presenter Module is managed on the HEMISPHERE® Site Dongle. For the access of the operators to configuration and operation a separate web client license is required for each operator (floating license).

Evidence Presenter Module

HEMISPHERE® EPM Module for structured documentation and presentation of all stored evidence (text, image, video, audio) of an Incident



Module License	
006162	DLD - HEMISPHERE® Evidence Presenter Module License for the use of the EPM module to create presentations to an event, for one instance of the HEMISPHERE® Backbone Server
Client License	
006284	DLD - HEMISPHERE® Web Client Access EPM License for the access of one web client to a HEMISPHERE® Evidence Presenter Module (floating license)
Server	
006007.415	 Server Rack-Mount 2 RU III Server hardware, 2RU rack-mount, 2x 12-core 2.2GHz CPU, 128 GB DDR4-2400 RAM, 2x redundant power supplies, 1x SATA DOM 64GB, 2x SSD 1000 GB with RAID 1 (in tray), 6x 3,5" HDDs optional, RAID 6, License for VMware ESXi 6.5 included



See more.