

SMAVIA licensing model

The SMAVIA licensing model is attracted by the fact that no license is required for the Viewing Client. The entire handling of software variants and license dongle is eliminated. The licensing is based centrally on the Recording Server.

Features

- Unified and centralized license management on the Recording Server
- Only one programme, download from the Recording Server or Internet
- Hardware license dongle no longer required
- Industry standard and tiered licensing model
- One Basic License is included in the Recording Server
- Compatibility license and dongle for the access on recorders of the generation 3 and 4 (optional)

Basic License

BL

- Included in every Recording Server
- Allows the access of one Viewing Client at full functional range
- A Viewing Client can access only one dedicated Recording Server with Basic License
- When a Floating License is purchased, the Basic License is converted into a Floating License (2 FL in result)

Floating License

FL

- Optionally available for every Recording Server
- Allows the access of one Viewing Client on several Recording Servers with Floating License
- Allows the simultaneous access of several Viewing Clients on one Recording Server, corresponding to the number of licenses
- Arbitrary Viewing Clients can connect to a vacant Floating License (no assignation)
- Viewing Client with access to a Floating License is comparable with the full version of PView 7

Compatibility License PView 7

- Allows a Viewing Client to access recorders of the generation 3 and 4
- Allows mixed operation with SMAVIA Recording Server and recorders of the generation 3 and 4
- Hardware license dongle included in the scope of delivery
- Existing PView 7 dongles can be used further on

 = Basic License

 = Floating License



Connection options with Basic Licenses: **BL** = Basic License


Only one Recording Server with Basic License can be configured in the Viewing Client (only one entry possible).

Basic Licenses are sufficient when:


- one Viewing Client is to access only one Recording Server (Simple Access)
- several Viewing Clients are to access one Recording Server one after the other (Temporally Separated Access)

FL⁺ = Number of purchased access licenses for the SMAVIA Viewing Client:

Simple Access



Temporally Separated Access




Connection options with Floating Licenses: **FL** = Floating License

Several Recording Server with Floating License can be configured in the Viewing Client (several entries possible).

Floating Licenses are only required when:

- one Viewing Client is to access several Recording Servers (Multiple Access)
- several Viewing Clients are to access one Recording Server at the same time (Simultaneous Access)

Multiple Access



Simultaneous Access

